



## **Popcorn Machine Operation Manual**

1. Plug the cord to the Popcorn Machine and to the outlet
2. Turn Light button On
3. Turn Heat button On
4. Wait for 4-5 minutes
5. Pour the content of popcorn kit (oil first) into the heated bowl
6. Turn Mixer button on
7. Wait for the popcorn to pop up
8. When popcorn finished popping up, empty the heated bowl.
9. If you don't need to prepare next kit immediately, turn Mixer button off and turn Heat button off

*In case of equipment malfunction or damage, stop the operation and contact Party  
Jump Rentals Inc at 613-880-7165*